Cold gas UV analyser





Cold-dry spectrometer-based gas analyser for measurement of pollutants in flue gas with low concentrations and for process control

APPLICATION

The UV analyser UVA 17 CD can be used for monitoring of e.g. NO, NO_2 , SO_2 and O_2 in incineration plants as well as for process measurements in the chemical and pharmaceutical industry.

This analyser is based on a spectrometer and measures all UV absorbing gas components. The applied Xenon flash light is characterised by a 2 to 3 times higher lifetime compared to other light sources.

The oxygen measurement is carried out optionally by a paramagnetic oxygen sensor or an electrochemical cell.

A small PC with 7" colour display and an app-based menu allow an intuitive operation on site as well as remotely.

LOWEST MEASURING RANGES	
Component	Measuring range
NO:	050 mg/m³
NO ₂ :	0100 mg/m ³
SO ₂ :	050 mg/m³
O ₂ :	025 vol. %
Other components (e.g. CH_2O , H_2S , CI_2) and measuring ranges on request.	


YOUR BENEFITS AT A GLANCE

- · compact design
- · long-term stable signal
- user-friendly touch display
- extension of measuring components without additional hardware possible
- remote access

PRECONDITIONS ON SITE

- · installation place indoors and dust-free
- · protection against wetness
- protection against percussions/vibrations
- · appropriate gas sampling and conditioning

SCHEMATIC DESIGN



FUNCTION

The function of the UV analyser is based on the measurement of an integrated spectrometer in the spectral range of ultraviolet radiation of 180 to 400 nm. Fundamentally, the device is composed of light source, measuring cell and spectrometer which are interconnected via the optical path. The emitted radiation is absorbed partly by the process gas in the measuring cell and detected by a spectrometer afterwards. By using a chemometric model the gas component as well as the concentration can be determined.

Because of the modular design, there is the possibility for application of different spectrometers for adaptation to variable requirements.

robust housing with compact 19" format, IP40; 483 mm x 133 mm x 350 mm (w x h x d), approx. 12 kg • spectrometer 180-400 nm (NO ₂ , SO ₂ , NO, CH ₂ O, H ₂ S, Cl ₂) • electrochemical cell (optional for O ₂) • paramagnetic measuring method (optional for O ₂) up to 12 components (dependent on application) and oxygen < 2% of the respective measuring range • warm-up time: < 1 h (at 20 °C ambient temperature) • zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or after longer storage)
 spectrometer 180-400 nm (NO₂, SO₂, NO, CH₂O, H₂S, Cl₂) electrochemical cell (optional for O₂) paramagnetic measuring method (optional for O₂) up to 12 components (dependent on application) and oxygen 2% of the respective measuring range warm-up time: < 1 h (at 20 °C ambient temperature) zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
 electrochemical cell (optional for O₂) paramagnetic measuring method (optional for O₂) up to 12 components (dependent on application) and oxygen 2% of the respective measuring range warm-up time: < 1 h (at 20 °C ambient temperature) zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
 paramagnetic measuring method (optional for O₂) up to 12 components (dependent on application) and oxygen 2% of the respective measuring range warm-up time: < 1 h (at 20 °C ambient temperature) zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
up to 12 components (dependent on application) and oxygen < 2% of the respective measuring range • warm-up time: < 1 h (at 20 °C ambient temperature) • zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
< 2% of the respective measuring range • warm-up time: < 1 h (at 20 °C ambient temperature) • zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
 warm-up time: < 1 h (at 20 °C ambient temperature) zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
• zero point drift: < ± 0.1% O2 / week (possibly higher at first commissioning or
the state of the s
after longer storage)
temperature influence:
- at zero point setting: < ± 0.05% O2 / °C
- at reference point setting: < ± 0.2% of meas. value / °C
540 °C (temperature stability max. 5 K/h); humidity: max. 90% (non-condensing)
path length of measuring cell: adjustable, 730 mm
• particle filter: 2 μm
automatically with ambient air
via internal pump: • flow rate: max. 2.6 l/min
now rate. max. 2.0 //min pressure: max. 1 bar
vacuum: max. 350 mbar
7" touch display, 800 x 480 Pixel, status messages for failure, maintenance and
maintenance request; Language selection: German, English, French, Chinese
data logger function
RS232 (Modbus)
 8 analogue outputs, 420 mA, potential-free, burden max. 500 Ω
• 14 digital inputs (optocoupler), max. 30 V
• 16 digital outputs, potential-free, max. 60 V, 500 mA
VNC, remote control via PC
110-250 V AC / 50-60 Hz, 50 W
integrated flow measurement

Dr. Födisch Umweltmesstechnik AG -

Zwenkauer Strasse 159 • 04420 Markranstädt • Germany

Phone: +49 34205 755-0 • Fax: +49 34205 755-40

E-mail: sales@foedisch.de

